

Maintenance chart

Service_Interval	Page Nb.	Service_Points	Nb. of pts	Change fluid			
				Drain fluid			Replace
				Grease			
				Check	Cleaning		
INITIAL 10 HOURS	Operating Instructions	Wheel bolt and nut torque		X			
	Alternator and air conditioning compressor (if equipped) belt tension	Alternator and air conditioning compressor (if equipped) belt tension for models SR130, SR160, SR175, and SV185 only		X			
EVERY 10 HOURS OR DAILY	Clean tracks and components	Clean tracks and components		X			
	Engine and hydraulic coolers	Engine and hydraulic coolers		X			
	Engine coolant level	Engine coolant level		X			
	Engine oil level	Engine oil level		X			
	Lift arm, pivot points, coupler pins and cylinder pins	Lift arm, pivot points, coupler pins and cylinder pins				X	
	Hydraulic oil level	Hydraulic oil level			X		

Service_Interval	Page Nb.	Service_Points	Nb. of pts	Cleaning				Check		Grease		Replace		Drain fluid		Change fluid			
		Seat belt, lap bar and seat interlock operation check						X											
INITIAL 50 HOURS	Final drive chain tank oil	Final drive chain tank oil						X											
EVERY 50 HOURS	Cab intake filter	Cab intake filter						X											
	Alternator and air conditioning compressor (if equipped) belt tension	Alternator and air conditioning compressor (if equipped) belt tension for models SR130, SR160, SR175, and SV185 only						X											
	Roll Over Protective Structure (ROPS) mechanism and hardware check	Roll Over Protective Structure (ROPS) mechanism and hardware check						X											

Service_Interval	Page Nb.	Service_Points	Nb. of pts	Cleaning				Change fluid
				Check		Grease	Replace	
				Drain fluid				
				Grease				
INITIAL 100 HOURS	Final drive oil (track models)	Final drive oil (track models)						X
EVERY 250 HOURS	In-line fuel filter	In-line fuel filter for models SR130 and SR160 only				X		
	Fuel pre-filter	Fuel prefilter					X	
	Drive chain tension check	Drive chain tension check		X				
EVERY 500 HOURS	Engine oil and filter	Engine oil and filter						X
	Fuel pre-filter	Fuel prefilter				X		
	Fuel filter	Fuel filter				X		
	Hydraulic oil filter	Hydraulic oil filter				X		
	Final drive chain tank oil	Final drive chain tank oil		X				
	Air cleaner elements	Air cleaner elements				X		
	Hardware - loose or damaged	Hardware - loose or damaged		X				

Service_Interval	Page Nb.	Service_Points	Nb. of pts	Cleaning					Change fluid	
				Check						
				Grease						
				Replace						
				Drain fluid						
	Final drive oil (track models)	Final drive oil (track models)								X
EVERY 1000 HOURS	Hydraulic systems - Change fluid	Hydraulic fluid and filter								X
	Final drive chain tank oil	Final drive chain tank oil								X
	Oil Mist Separator (OMS) filter	Oil Mist Separator (OMS) filter for models SR130, SR160, SR175, and SV185					X			
EVERY 2000 HOURS	Engine coolant drain and flush	Engine coolant drain and flush								X
	Blow-by re-circulation filter	Blowby re-circulation filter for models SR210, SR220, SR250, SV250, SV300, TR270, TR320, and TV380 only					X			
EVERY 4000 HOURS	Diesel Particulate Filter (DPF)	Diesel Particulate Filter (DPF)					X			
AS REQUIRED	Diesel Particulate Filter (DPF)	Diesel Particulate Filter (DPF)		X						