

Maintenance chart

Service_Points	Grease				Change fluid				
	Check	Cleaning			Replace				
					Drain fluid				
								Page Nb.	
EVERY 10 HOURS OR DAILY									
Clean tracks and components	x								Clean tracks and components
Wheels and tires		x							Wheels and tires
Engine and hydraulic coolers		x							Engine and hydraulic coolers
Engine coolant level		x							Engine coolant level
Engine oil level		x							Engine oil level
Loader arm pivot points, coupler pins, and cylinder pins			x						Loader arm pivot points, coupler pins, and cylinder pins
Hydraulic oil level		x							Hydraulic oil level
Loader arm and bucket hydraulic interlock		x							Loader arm and bucket hydraulic interlock
INITIAL 50 HOURS									
Final drive oil (track models)					x				Final drive oil (track models)
EVERY 50 HOURS									
Cab intake filter		x							Cab intake filter
Alternator and air conditioning compressor (if equipped) belt tension (models SR130, SR160, SR175, and SV185 only)		x							Alternator and air conditioning compressor (if equipped) belt tension (models SR130, SR160, SR175, and SV185 only)
Roll Over Protective Structure (ROPS) mechanism and hardware check		x							Roll Over Protective Structure (ROPS) mechanism and hardware check
EVERY 250 HOURS									
In-line fuel filter (models SR130 and SR160 only)						x			In-line fuel filter (models SR130 and SR160 only)
Fuel prefilter							x		Fuel prefilter
Drive chain tension check		x							Drive chain tension check
EVERY 500 HOURS									
Engine oil and filter					x				Engine oil and filter
Fuel prefilter						x			Fuel prefilter
Fuel filter						x			Fuel filter
Hydraulic oil filter						x			Hydraulic oil filter
Final drive chain tank oil		x							Final drive chain tank oil
Air cleaner elements							x		Air cleaner elements
Hardware - loose or damaged		x							Hardware - loose or damaged
Final drive oil (track models)						x			Final drive oil (track models)
EVERY 1000 HOURS									

Service_Points	Grease				Change fluid				
	Check				Replace				
	Cleaning				Drain fluid				
					Page Nb.				
Hydraulic fluid and filter					x				Hydraulic fluid and filter
Final drive chain tank oil					x				Final drive chain tank oil
Oil Mist Separator (OMS) filter (models SR130, SR160, SR175, and SV185 only)					x				Oil Mist Separator (OMS) filter (models SR130, SR160, SR175, and SV185 only)
EVERY 2000 HOURS									
Engine cooling system - Change fluid – SR130, SR160, SR175, and SV185 only					x				Engine cooling system - Change fluid - SR130, SR160, SR175, and SV185 only
Engine cooling system - Change fluid – SR210, SR240, SV280, TR270, and TR310 only					x				Engine cooling system - Change fluid - SR210, SR240, SV280, TR270, and TR310 only
Blow-by recirculation system (models SR210, SR240, SV280, TR270, and TR310 only)					x				Blow-by recirculation system (models SR210, SR240, SV280, TR270, and TR310 only)
EVERY 4000 HOURS									
Diesel Particulate Filters (DPF) - Cleaning (models SR130 and SR160 only)	x								Diesel Particulate Filters (DPF) - Cleaning (models SR130 and SR160 only)
AS REQUIRED									
Auto-regeneration	x								Auto-regeneration
Manual regeneration	x								Manual regeneration