

Maintenance chart

Service_Points	Grease				Change fluid			
	Cleaning	Check			Drain fluid	Replace		
		Page Nb.						
EVERY 10 HOURS OR DAILY								
Clean tracks and components	x							Clean tracks and components
Wheels and tires		x						Wheels and tires
Engine and hydraulic coolers		x						Engine and hydraulic coolers
Engine coolant level		x						Engine coolant level
Engine oil level		x						Engine oil level
Loader arm pivot points, coupler pins, and cylinder pins			x					Loader arm pivot points, coupler pins, and cylinder pins
Hydraulic oil level		x						Hydraulic oil level
Loader arm and bucket hydraulic interlock		x						Loader arm and bucket hydraulic interlock
INITIAL 50 HOURS								
Final drive oil (track models)				x				Final drive oil (track models)
EVERY 50 HOURS								
Cab intake filter		x						Cab intake filter
Alternator and air conditioning compressor (if equipped) belt tension (models SR130, SR160, SR175, and SV185 only)		x						Alternator and air conditioning compressor (if equipped) belt tension (models SR130, SR160, SR175, and SV185 only)
Roll Over Protective Structure (ROPS) mechanism and hardware check		x						Roll Over Protective Structure (ROPS) mechanism and hardware check
EVERY 250 HOURS								
In-line fuel filter (models SR130 and SR160 only)					x			In-line fuel filter (models SR130 and SR160 only)
Fuel prefilter						x		Fuel prefilter
Drive chain tension check		x						Drive chain tension check
EVERY 500 HOURS								
Engine oil and filter				x				Engine oil and filter
Fuel prefilter					x			Fuel prefilter
Fuel filter					x			Fuel filter
Hydraulic oil filter					x			Hydraulic oil filter
Final drive chain tank oil		x						Final drive chain tank oil
Air cleaner elements						x		Air cleaner elements
Hardware - loose or damaged		x						Hardware - loose or damaged
Final drive oil (track models)					x			Final drive oil (track models)
EVERY 1000 HOURS								

Service_Points	Grease				Change fluid				
	Check				Replace				
	Cleaning				Drain fluid				
					Page Nb.				
Hydraulic fluid and filter					x				Hydraulic fluid and filter
Final drive chain tank oil					x				Final drive chain tank oil
Oil Mist Separator (OMS) filter (models SR130, SR160, SR175, and SV185 only)					x				Oil Mist Separator (OMS) filter (models SR130, SR160, SR175, and SV185 only)
EVERY 2000 HOURS									
Engine cooling system - Change fluid – SR130, SR160, SR175, and SV185 only					x				Engine cooling system - Change fluid - SR130, SR160, SR175, and SV185 only
Engine cooling system - Change fluid – SR210, SR240, SV280, TR270, and TR310 only					x				Engine cooling system - Change fluid - SR210, SR240, SV280, TR270, and TR310 only
Blow-by recirculation system (models SR210, SR240, SV280, TR270, and TR310 only)					x				Blow-by recirculation system (models SR210, SR240, SV280, TR270, and TR310 only)
EVERY 4000 HOURS									
Diesel Particulate Filters (DPF) - Cleaning (models SR130 and SR160 only)	x								Diesel Particulate Filters (DPF) - Cleaning (models SR130 and SR160 only)
AS REQUIRED									
Auto-regeneration	x								Auto-regeneration
Manual regeneration	x								Manual regeneration