

## Maintenance chart

Service_Interval	Page Nb.	Service_Points	Nb. of pts	Change fluid			
				Drain fluid			Replace
				Grease			
				Check	Cleaning		
INITIAL 10 HOURS	<b>Operating Instructions</b>	Wheel bolt and nut torque		X			
	<b>Alternator and air conditioning compressor (if equipped) belt tension</b>	Alternator and air conditioning compressor (if equipped) belt tension for models SR130, SR160, SR175, and SV185 only		X			
EVERY 10 HOURS OR DAILY	<b>Clean tracks and components</b>	Clean tracks and components		X			
	<b>Engine and hydraulic coolers</b>	Engine and hydraulic coolers		X			
	<b>Engine coolant level</b>	Engine coolant level		X			
	<b>Engine oil level</b>	Engine oil level		X			
	<b>Lift arm, pivot points, coupler pins and cylinder pins</b>	Lift arm, pivot points, coupler pins and cylinder pins			X		
	<b>Hydraulic oil level</b>	Hydraulic oil level		X			

		Change fluid				
		Drain fluid				
		Replace				
		Grease				
		Check				
		Cleaning				
Service_Interval	Page Nb.	Service_Points	Nb. of pts			
	<b>Seat belt, restraint bar, and seat interlock operation check</b>	Seat belt, lap bar and seat interlock operation check		X		
INITIAL 50 HOURS	<b>Final drive chain tank oil</b>	Final drive chain tank oil		X		
EVERY 50 HOURS	<b>Cab intake filter</b>	Cab intake filter		X		
	<b>Alternator and air conditioning compressor (if equipped) belt tension</b>	Alternator and air conditioning compressor (if equipped) belt tension for models SR130, SR160, SR175, and SV185 only		X		
	<b>Roll Over Protective Structure (ROPS) mechanism and hardware check</b>	Roll Over Protective Structure (ROPS) mechanism and hardware check		X		

Service_Interval	Page Nb.	Service_Points	Nb. of pts	Cleaning					Change fluid	
				Check			Grease	Replace		Drain fluid
				Cleaning		Grease				
				Check	Replace					
INITIAL 100 HOURS	Final drive oil (track models)	Final drive oil (track models)							X	
EVERY 250 HOURS	In-line fuel filter	In-line fuel filter for models SR130 and SR160 only					X			
	Fuel pre-filter	Fuel prefilter						X		
	Drive chain tension check	Drive chain tension check		X						
EVERY 500 HOURS	Engine oil and filter	Engine oil and filter							X	
	Fuel pre-filter	Fuel prefilter					X			
	Fuel filter	Fuel filter					X			
	Hydraulic oil filter	Hydraulic oil filter					X			
	Final drive chain tank oil	Final drive chain tank oil		X						
	Air cleaner elements	Air cleaner elements					X			
	Hardware - loose or damaged	Hardware - loose or damaged		X						

Service_Interval	Page Nb.	Service_Points	Nb. of pts	Cleaning					Change fluid	
				Check						
				Grease						
				Replace						
				Drain fluid						
	<b>Final drive oil (track models)</b>	Final drive oil (track models)								X
EVERY 1000 HOURS	<b>Hydraulic systems - Change fluid</b>	Hydraulic fluid and filter								X
	<b>Final drive chain tank oil</b>	Final drive chain tank oil								X
	<b>Oil Mist Separator (OMS) filter</b>	Oil Mist Separator (OMS) filter for models SR130, SR160, SR175, and SV185					X			
EVERY 2000 HOURS	<b>Engine coolant drain and flush</b>	Engine coolant drain and flush								X
	<b>Blow-by re-circulation filter</b>	Blowby re-circulation filter for models SR210, SR220, SR250, SV250, SV300, TR270, TR320, and TV380 only					X			
EVERY 4000 HOURS	<b>Diesel Particulate Filter (DPF)</b>	Diesel Particulate Filter (DPF)					X			
AS REQUIRED	<b>Diesel Particulate Filter (DPF)</b>	Diesel Particulate Filter (DPF)		X						