

Maintenance chart

Interval	Page Nb.	Maintenance Action	Nb. of pts	Cleaning				Check		Grease		Drain fluid		Change fluid		Replace			
EVERY 10 HOURS OR EACH DAY	Clean tracks and components	Clean tracks and components		X															
	Engine and hydraulic coolers	Clean engine and hydraulic coolers		X															
	Engine coolant reservoir level check	Engine coolant reservoir level			X														
	Engine oil	Engine oil level			X														
	Lift arm, pivot pins, coupler pins, and cylinder pins	Lift arm, pivot pins, coupler pins, and cylinder pins					X												
	Hydraulic system	Hydraulic system oil level			X														
	Clean tracks and components	Track tension			X														

				Replace	
				Change fluid	
				Drain fluid	
				Grease	
				Check	
				Cleaning	
Interval	Page Nb.	Maintenance Action	Nb. of pts		
	Seat belt, restraint bar, and seat interlock operation	Seat belt, restraint bar, and seat interlock operation check		X	
	Alternator and air conditioning compressor (if equipped) belt tension	Alternator and air conditioning compressor (if equipped) belt tension (Initial)		X	
	Operating Instructions	Wheel nut torque		X	
EVERY 50 HOURS	Alternator and air conditioning compressor (if equipped) belt tension	Alternator and air conditioning compressor (if equipped) belt tension		X	
	Final track drive oil change - initial	Final track drive oil change (Initial)			X
	Engine oil and filter	Engine oil and filter (Initial) F5C 3.2L; ISM 2.0L and 2.2L			X

Interval	Page Nb.	Maintenance Action	Nb. of pts	Cleaning				Check	Grease	Drain fluid	Change fluid	Replace
				Cleaning								
				Cleaning								
				Cleaning								
	Roll Over Protective Structure (ROPS) mechanism and hardware check	Roll Over Protective Structure (ROPS) mechanism and hardware check (Initial)					X					
	Hardware - loose or damaged	Hardware — loose or damaged (Initial)					X					
	Seat belt precautions	Seat belt					X					
	Clean tracks and components	Track tension					X					
EVERY 250 HOURS	Fuel filter	Fuel filter							X			
	Drive chain tension check	Drive chain tension check (Initial)					X					
	Radiator coolant level check	Radiator coolant level check (Reservoir)					X					
	Engine oil and filter	Engine oil and filter — ISM 2.0L								X		
	Inline fuel filter - replace	Inline fuel filter									X	

Interval	Page Nb.	Maintenance Action	Nb. of pts	Cleaning					Replace
				Check		Grease			
				Drain fluid		Change fluid			
				Replace		Change fluid			
	Wheels and tires	Tire air pressure		X					
EVERY 500 HOURS	Air cleaner elements	Air cleaner elements							X
	Engine oil and filter	Engine oil and filter						X	
	Final drive chain tank oil	Final drive chain tank oil		X					
	Primary fuel filter	Primary fuel filter							X
	Hydraulic oil filter	Hydraulic oil filter							X
	Roll Over Protective Structure (ROPS) mechanism and hardware check	Roll Over Protective Structure (ROPS) mechanism and hardware check		X					
	Hardware - loose or damaged	Hardware — loose or damaged		X					
	Final track drive oil	Final track drive oil						X	

Interval	Page Nb.	Maintenance Action	Nb. of pts	Cleaning		Check	Grease	Drain fluid	Change fluid	Replace
EVERY 1000 HOURS		Engine valve clearance				X				
	Hydraulic systems - Change fluid	Hydraulic fluid and filter								X
	Radiator drain and flush	Radiator drain and flush								X
	Final drive chain tank oil	Final drive chain tank oil								X